

ULTRASONIC DIFFUSER



UltraSonic Diffuser

TRUessence is proud to announce its new state-of-the-art ultrasonic essential oil diffuser. Aside from cold air diffusion, it has humidifying effects and multiple settings to bring the plant kingdom into your living room. A must!

Product Features

- **Safety:** No risk of over heating and/or explosion since the cool mist is generated by ultrasonic, not a flame or any kind of heat.
- **User Friendly:** Level of mist and output duration can be adjusted to reflect your own personal needs.
 - **Operation:** Once filled the unit can operate for up to 5 hours.
 - **Digital Control:** Digitally programmed to stop automatically when the minimum water level is reached. Energy efficient.
 - **Functions:** Can be used as humidifier, nebulizer or air purifier.

SPECIFICATIONS

External Dimension	17.5 cm x 15 cm x 11 cm
Transformer	110V-24V/750mA : 220V-24V/750mA
Maximum working voltage	24V/750mA
Maximum input	18W
Operation frequency	1.7 MHZ
Atomizing rate	50-60ml/hr (max)
Particle size	Approx. 3 micro-meter
Controls	<ul style="list-style-type: none">• On/Off switch• Output control in the center; turn clockwise to increase output, turn counterclockwise to decrease.• Timer switch (5 settings):<ol style="list-style-type: none">1. Unit works continuously until low water level is reached and will automatically stop.2. Unit works continuously for 2 hours and will automatically stop.3. Unit disperses for 5 seconds and rest for 40 seconds.4. Unit disperses for 15 seconds and rest for 50 seconds.5. Unit disperses for 30 minutes and rest for 15 minutes.
Accessory	Humidifier, transformer, dispersal nozzle, cover.
Water level	0,5 cm (0.20 inch) below water blocking cover.
Water level safety stop	Operates at 1.3 (0.50 inch) cm of water in tank.
Capacity of tank	250 ml

Operating Instructions



1. Remove the cover & vaporizing nozzle (number 1-3).
2. Fill the water tank with water. The minimum level is 1.3 cm (0.50 inch) and the maximum is 0.5 cm (0.20 inch) below the cover.
3. Add 3 to 5 drops of your favorite essential oil to the water.
4. Replace the cover and vaporizing nozzle.
5. Dry hands and plug the power supply in to the underside of the unit.
6. Plug the adaptor into a standard household outlet.
7. Press the On/Off switch to the On position (number 9).
8. Select the preferred time period (number 10).
9. Adjust the output control (number 11) to the desirable mist rate. Turn clockwise to increase output, turn counterclockwise to decrease.
10. Do not immerse the unit in water and do not overfill.



TRUessence